







Y3-180L-B3
Mounting diagram



Y3-180L-B5
Mounting diagram



Y3-180L-B35
Mounting diagram



Y3-180L-V1
Mounting diagram