NOVA-L

General Description

- Ergonomic and robust design
- TÜV certified according to EN ISO 13849-1 and EN 62061
- Key switch, stop button, toggle switches, push buttons, joysticks in X/Y direction with digital or stepless functions, belly belt or neck strap
- Receiver programming via transmitter possible (Quick-Set)
- Standard and costumised solutions
- Optional cable control
- Feedback via LED and display available
- Tandem operation optional
- Integrated battery charging function possible





Control Functions and Accessories

- Start button
- Key switch
- Stop button
- Toggle switch
- S Knob-operated switch
- 3 Joystick
- LED status display
- Original ABITRON battery charger and battery





Safety Precautions

Attention: Make sure that you have read and fully understood the manuals to both the safety radio

remote control and the machine to be operated prior to commissioning!

Always check if the stop function is working properly before operating the machine.

Please check the following points prior to each machine operation!

✓ Inspect the transmitter for possible damage

✓ Check the function of the stop button
⑤ by means of the LED status display
⑥ (Transmitter on: LED flashes / if stop button is activated: LED flashes faster)

Transmitter Operation

The transmitter may only be operated by trained and authorised personnel! Insert a fully charged battery into the battery compartment on the bottom of the transmitter. Start the transmitter by turning the key switch ❷. The LED status display ❷ must flash green now and a buzzing sound will confirm the system check (approx. 2 seconds). After the startup procedure you can start the system with the start button ④. With the joystick ⑤ and the toggle switches ④ you can activate the designated function. The activated functions are now being transmitted to the receiver. The specific functions of the buttons/switches are described in the enclosed drawing! You can stop the system by engaging the stop button ⑤ (conduct only in case of emergency).

LED status display: Flashing = Transmitter is ready for operation

Buzzer: An interval signal gives notice in case of low battery voltage. After approx. 30 seconds the

transmitter will shut down.

Technical Data

Material pol	yamide with glass fibre
Weight app	prox. 1600 g
Diagnostics sta	tus LED
RF technology syr	nthesizer
RF output < 1	10 mW
Temperature range -25	5 up to +70° C
Antenna inte	ernal or external
Frequency range 434	4/869 MHz (for EU, other frequencies upon request)
Safety address 20	bit (1 Mio.)
Protection type IP	65
Operating time 20	hours and more
Power supply 3,6	S VDC

